



# EZ-Set™ ELISA Kit (DIY Antibody Pairs)

Catalog number: EZ0928

For the development of sandwich ELISA kit to measure **Human F3** concentrations in cell culture supernatants, serum, plasma (heparin, EDTA, citrate), Cell lysates, and urine.

This package insert must be read in its entirety before using this product.

For research use only. Not for use in diagnostic procedures.



# Human Tissue Factor/F3 ELISA Kit EZ-Set™ (DIY Antibody Pairs)

Catalog Number: EZ0928

For the development of sandwich ELISA kit to measure Human F3 in cell culture supernatants, serum, plasma (heparin, EDTA, citrate), Cell lysates, and urine.

This kit contains sufficient materials to run ELISAs on at least five 96 well plates, provided the following conditions are met:

- The reagents are prepared as described in this package insert.
- The assay is run as described in the General ELISA Protocol.
- The recommended microplates, buffers, diluents, substrates, and solutions are used.

#### Overview

Size	5 plates/kit		
Range	15.6 pg/ml - 1,000 pg/ml		
Specificity	Natural and recombinant Human F3		
Immunogen	Expression system for standard: NSO; Immunogen sequence: S33-E251		
Cross Reactivity	There is no detectable cross-reactivity with other relevant proteins.		
Storage Instructions  Store at 4°C for 6 months, at -20°C for 12 months. Avoid multiple freeze-thaw cycles (Sh ice, can store for up to 3 days in room temperature. Freeze upon receiving.)			

# Kit Components/Materials Provided

Catalog number	Description	Quantity	Storage of opened/reconstituted material	
EZ0928-CA	Rabbit anti- human F3 polyclonal antibody (Capture Antibody)	500 µl, 0.4 mg/mL (recommended dilution 1:100)	Store undiluted at 4°C for 1 month or at -20°C for 3 months provided this is	
EZ0928-DA	Biotinylated goat anti- human F3 polyclonal antibody (Detection Antibody)	500 µl, 5 µg/mL (recommended dilution 1:100)	within the expiration date of the kit.	
AR1103	Avidin-Biotin-Peroxidase Complex (ABC)	500 μl (recommended dilution 1:100)		
EK0928-ST	Lyophilized recombinant human F3 standard	10 ng/tube×3	Discard the standard stock solution after 12 hours at 4°C. May be stored at -20°C for 48 hours provided this is within the expiration date of the kit.	



## Other Materials & Solutions Required But Not Provided

- 1. Microplate reader in standard size.
- 2. Automated plate washer.
- 3. Incubator.
- 4. Adjustable pipettes and pipette tips. Multichannel pipettes are recommended in the condition of large amount of samples in the detection.
- 5. Clean tubes and Eppendorf tubes.
- 6. 96 well microplate (Cat# AR1100)
- 7. Plate Sealers.
- 8. Capture Antibody Diluent: PBS.
- 9. Reagent Diluent: 1% BSA in PBS, pH 7.2-7.4, 0.2 um filtered.
- 10. Color Developing Reagent: Tetramethylbenzidine (Cat# AR1104)
- 11. Stop Solution: 2 N H2SO4 (Cat# AR1105)
- 12. Wash Buffer (PBS and PBS-T).

PBS: 8g NaCl, 0.2g KCl, 1.15g Na2HPO4, 0.2g KH2PO4, adjust the total volume to 1 L with distilled water, pH 7.2-7.4, 0.2 um filtered.

PBS-T: 0.1% Tween? 20 in PBS, pH 7.2-7.4.

\*Item 6 - 12 are included in the EZ Set Accessory Kit (EZA001)

## **Preparation**

Bring all reagents to room temperature before use. Working dilutions should be prepared and used immediately.

#### 1. Plate Preparation

- 1) Dilute the Capture Antibody to the working concentration in 1:100 with Capture Antibody Diluent. (i.e. Add 1 µl anti-Human F3 Capture Antibody into 99 µl Capture Antibody Diluent.) Immediately coat a 96-well microplate with 100 µl per well of the diluted Capture Antibody. Seal the plate and incubate overnight at 4°C.
- 2) Remove the cover and discard the liquid in the wells into an appropriate waste receptacle. Invert the plate on the benchtop onto a paper towel and tap the plate to gently blot any remaining liquid. It is recommended that the wells are not allowed to completely dry at any time.
- 3) Block plates by adding 200 µl of Reagent Diluent to each well. Incubate at room temperature for 2 hours.
- 4) Aspirate each well and wash with **PBS**, repeating the process two times for a total of three washes. Wash by filling each well with **PBS** (300-350 µl) using a squirt bottle, manifold dispenser, or autowasher. Complete removal of liquid at each step is essential for good performance. After the last wash, remove any remaining **PBS** by aspirating or by inverting the plate and blotting it against clean paper towels. (**Plate Washing Method**)

#### 2. Reconstitution of Human F3 standard

1) It is recommended that the standards be prepared no more than 2 hours prior to performing the experiment. Use one 10 ng of lyophilized human F3 standard for each experiment. Gently spin the vial prior to use. Reconstitute the standard to a stock concentration of 10 ng/ml using 1 ml of Reagent Diluent. Allow the standard to sit for a minimum of 10 minutes with gentle agitation prior to making dilutions.

- 2) Dilution of Human F3 Standard
- Number tubes 1 8. Final Concentrations to be Tube # 1 1,000 pg/ml, # 2 500 pg/ml, # 3 250 pg/ml, # 4 125 pg/ml, # 5 62.5 pg/ml, # 6 31.2 pg/ml, # 7 15.6 pg/ml, # 8 0.0 (Blank).
- To generate standard # 1, add 100  $\mu$ l of the reconstituted standard stock solution of 10 ng/ml and 900  $\mu$ l of Reagent Diluent to tube # 1 for a final volume of 1,000  $\mu$ l. Mix thoroughly.
- Add 300 µl of Reagent Diluent to tubes # 2 7.
- $\bullet$  To generate standard # 2, add 300  $\mu$ l of standard # 1 from tube # 1 to tube # 2 for a final volume of 600  $\mu$ l. Mix thoroughly.
- To generate standard # 3, add 300 μl of standard # 2 from tube # 2 to tube # 3 for a final volume of 600 μl. Mix thoroughly.
- Continue the serial dilution for tube #4 7.



• Tube # 8 is a blank standard to be used with every experiment.

#### 3. Preparation of Rabbit anti-human F3 polyclonal antibody working solution

- 1) Each vial contains 500 µl of Rabbit anti-human F3 polyclonal antibody.
- 2) Rabbit anti- human F3 polyclonal antibody should be diluted in 1:100 with Capture Antibody Diluent and mixed thoroughly. (i.e. Add 1  $\mu$ l Rabbit anti- human F3 polyclonal antibody to 99  $\mu$ l Capture Antibody Diluent.)

#### 4. Preparation of Biotinylated goat anti-human F3 polyclonal antibody working solution

- 1) Each vial contains 500 µl of Biotinylated goat anti-human F3 polyclonal antibody.
- 2) Biotinylated goat anti- human F3 polyclonal antibody should be diluted in 1:100 with Reagent Diluent and mixed thoroughly. (i.e. Add 1  $\mu$ l Biotinylated goat anti- human F3 polyclonal antibody to 99  $\mu$ l Reagent Diluent.)

#### 5. Preparation of Avidin-Biotin-Peroxidase Complex (ABC) working solution

- 1) Each vial contains 500 µl of Avidin-Biotin-Peroxidase Complex (ABC).
- 2) Avidin-Biotin-Peroxidase Complex (ABC) should be diluted in 1:100 with Reagent Diluent and mixed thoroughly. (i.e. Add 1 µl ABC to 99 µl Reagent Diluent.)

## **Assay Protocol**

It is recommended that all reagents and materials be equilibrated to room temperature (18-25°C) prior to the experiment (see Preparation Before The Experiment, if you have missed this information).

- 1. Prepare all reagents and working standards as directed previously.
- 2. Remove excess microplate strips from the plate frame and seal and store them in the original packaging.
- 3. Add 100 µl of the standard, samples, or control per well. At least two replicates of each standard, sample, or control is recommended.
- 4. Cover with the plate sealer provided and incubate for 120 minutes at room temperature (or 90 min. at 37 °C).
- 5. Remove the cover and discard the liquid in the wells into an appropriate waste receptacle. Invert the plate on the benchtop onto a paper towel and tap the plate to gently blot any remaining liquid. It is recommended that the wells are not allowed to completely dry at any time.
- 6. Add 100 µl of the prepared 1x Biotinylated goat anti-human F3 polyclonal antibody to each well.
- 7. Cover with a plate sealer and incubate for 90 minutes at room temperature (or 60 minutes at 37°C).
- 8. Wash the plate 3 times with PBS:
- a. Discard the liquid in the wells into an appropriate waste receptacle. Then, invert the plate on the benchtop onto a paper towel and tap the plate to gently blot any remaining liquid. It is recommended that the wells are not allowed to completely dry at any time.
- b. Add 300 µl of PBS to each assay well. (For cleaner background incubate for 60 seconds between each wash).
- c. Repeat steps a-b 2 additional times.
- d. Discard the wash buffer in the wells into an appropriate waste receptacle. Then, invert the plate on the benchtop onto a paper towel and tap the plate to gently blot any remaining liquid.
- 9. Add 100 µl of the prepared 1x Avidin-Biotin-Peroxidase Complex into each well and incubate for 40 minutes at RT (or 30 minutes at 37°C).
- 10. Wash the plate 5 times with PBS-T:
- a. Discard the liquid in the wells into an appropriate waste receptacle. Then, invert the plate on the benchtop onto a paper towel and tap the plate to gently blot any remaining liquid. It is recommended that the wells are not allowed to completely dry at any time.
- b. Add 300 µl of **PBS-T** to each assay well. (For cleaner background incubate for 60 seconds between each wash).
- c. Repeat steps a-b 4 additional times.
- d. Discard the wash buffer in the wells into an appropriate waste receptacle. Then, invert the plate on the benchtop onto a paper towel and tap the plate to gently blot any remaining liquid.
- 11. Add 90 µl of Color Developing Reagent to each well and incubate in the dark for 30 minutes at RT (or 25-30 minutes at 37°C). (The optimal incubation time must be empirically determined. A guideline to look for is blue shading the top four standard wells, while the remaining standards remain clear.)







- 12. Add 100 µl of Stop Solution to each well. The color should immediately change to yellow.
- 13. Within 30 minutes of stopping the reaction, the O.D. absorbance should be read with a microplate reader at 450nm.

## **Data Analysis**

Average the duplicate readings for each standard, sample, and control. Subtract the average zero standard O.D. reading.

It is recommended that a standard curve be created using computer software to generate a four-parameter logistic (4-PL) curve-fit. A free program capable of generating a four-parameter logistic (4-PL) curve-fit can be found online at: www.myassays.com/four-parameter-logistic-curve.assay.

Alternatively, plot the mean absorbance for each standard against the concentration. The measured concentration in the sample can be interpolated by using linear regression of each average relative O.D. against the standard curve generated using curve fitting software. This will generate an adequate but less precise fit of the data.

For diluted samples, the concentration reading from the standard curve must be multiplied by the dilution factor.

## Background on F3

Tissue factor, also called platelet tissue factor, factor III, thrombokinase, or CD142 is a protein present in sub endothelial tissue and leukocytes necessary for the initiation of thrombin formation from the zymogene prothrombin. An incorrect synonym is thromboplastin. the F3 gene was mapped to 1pter-p21 by study of somatic cell hybrids with a species-specific sensitive chromogenic assay. This gene encodes coagulation factor III which is a cell surface glycoprotein. This factor enables cells to initiate the blood coagulation cascades, and it functions as the high-affinity receptor for the coagulation factor VII.







## Submit a product review to Biocompare.com





Submit a review of this product to Biocompare.com to receive a \$20 Amazon giftcard! Your reviews help your fellow scientists make the right decisions. Thank you for your contribution.

Human Tissue Factor/F3 ELISA Kit EZ-Set™ (DIY Antibody Pairs)