EnzyChrom[™] Glycerol Assay Kit (Cat# EGLY-200)

Quantitative Colorimetric/Fluorimetric Glycerol Determination

DESCRIPTION

GLYCEROL [GLYCERIN or GLYCERINE, C3H5(OH)3] is widely used in foods, beverages and pharmaceutical formulations. It is also a main byproduct of biodiesel production. Simple, direct and automation-ready procedures for measuring glycerol concentrations find wide applications. BioAssay Systems' glycerol assay uses a single Working Reagent that combines glycerol kinase, glycerol phosphate oxidase and color reactions in one step. The color intensity of the reaction product at 570nm or fluorescence intensity at $\lambda em/ex = 585/530nm$ is directly proportional to glycerol concentration in the sample.

KEY FEATURES

Sensitive and accurate. Use as little as 10 µL samples. Linear detection range in 96-well plate: 10 to 1000 μM (92 $\mu g/dL$ to 9.2 mg/dL) glycerol for colorimetric assays and 2 to 50 µM for fluorimetric assays.

Simple and convenient. The procedure involves addition of a single working reagent and incubation for 20 min at room temperature, compatible for HTS assays.

Improved reagent stability. The optimized formulation has greatly enhanced the reagent and signal stability.

APPLICATIONS:

Direct Assays: glycerol in biological samples (e.g. serum and plasma). **Drug Discovery/Pharmacology:** effects of drugs on glycerol metabolism. Food and Beverages: glycerol in food, beverages, pharmaceutical formulations etc.

KIT CONTENTS

Assay Buffer: 24 mL Enzyme Mix: 500 µL **ATP**: 250 μL Dye Reagent: 220 µL Standard: 100 µL 100 mM Glycerol

Storage conditions. The kit is shipped on ice. Store all components at -20°C. Shelf life of 12 months after receipt.

Precautions: reagents are for research use only. Normal precautions for laboratory reagents should be exercised while using the reagents. Please refer to Material Safety Data Sheet for detailed information.

COLORIMETRIC 96-WELL PROCEDURE

Note: SH-group containing reagents (e.g. mercaptoethanol, DTT) may interfere with this assay and should be avoided in sample preparation.

1. Equilibrate all components to room temperature. Keep thawed Enzyme Mix in a refrigerator or on ice. Dilute standard in distilled water as follows (diluted standards can be used for future assays when stored refrigerated).

No	STD + H₂O	Vol (μL)	Glycerol (mM)
1	10 μL + 990 μL	1000	1.0
2	6 μL + 994 μL	1000	0.6
3	3 μL + 997 μL	1000	0.3
4	0 μL + 1000 μL	1000	0

Transfer 10 µL standards and 10 µL samples into separate wells of a clear 96-well plate.

- 2. For each reaction well, mix 100 µL Assay Buffer, 2 µL Enzyme Mix, 1 μ L ATP and 1 μ L Dye Reagent in a clean tube. This Working Reagent should be used on the same day of preparation. Transfer 100 μ L Working Reagent into each reaction well. Tap plate to mix.
- 3. Incubate 20 min at room temperature. Read optical density at 570nm (550-585nm).

Note: if the Sample OD is higher than the Standard OD at 1.0 mM, dilute sample in water and repeat the assay. Multiply result by the dilution factor.

CALCULATION

Subtract blank OD (water, #4) from the standard OD values and plot the OD against standard concentrations. Determine the slope using linear regression fitting. The glycerol concentration of Sample is calculated as

$$[Glycerol] = \frac{OD_{SAMPLE} - OD_{H2O}}{Slope} \quad (mM)$$

OD_{SAMPLE} and OD_{H2O} are optical density values of the sample and water. Conversions: 1mM glycerol equals 9.2 mg/dL, 92 ppm.

FLUORIMETRIC 96-WELL PROCEDURE

For fluorimetric assays, the linear detection range is 2 to 50 µM glycerol. Mix 10 µL 100 mM Standard with 990 µL H₂O (final 1 mM).

No	1 mM STD + H₂O	Vol (μL)	Glycerol (mM)
1	50 μL + 950 μL	1000	0.050
2	30 μL + 970 μL	1000	0.030
3	15 μL + 985 μL	1000	0.015
4	0 μL +1000 μL	1000	0

Dilute standards as above. Transfer 10 μL standards and 10 μL samples into separate wells of a black 96-well plate.

Add 100 µL Working Reagent (see Colorimetric Procedure). Tap plate to mix.


Incubate 20 min at room temperature and read fluorescence at λ_{ex} = 530nm and $\lambda_{em} = 585$ nm.

The glycerol concentration of Sample is calculated as

$$[Glycerol] = \frac{F_{SAMPLE} - F_{H2O}}{Slope} \quad (mM)$$

MATERIALS REQUIRED, BUT NOT PROVIDED

Pipeting devices, centrifuge tubes. Clear flat-bottom 96-well plates. black 96-well plates (e.g. Corning Costar) and plate reader.



PUBLICATIONS

- 1. Li, C et al (2020). Matrix Gla protein regulates adipogenesis and is serum marker of visceral adiposity. Adipocyte, 9(1), 68-76.
- 2. Fontvieille, A et al (2019). Acute effect of post-resistance exercise milk-based supplement on substrate oxidation and fat mobilization in older men: A pilot study. Advances in Geriatric Medicine and Research, 1(2).
- 3. Pan, Y., et al. (2018). Salvianolic acid B improves mitochondrial function in 3T3-L1 adipocytes through a pathway involving PPARgamma coactivator-1alpha (PGC-1alpha). Frontiers in pharmacology, 9:671.